

16898, 16899 - USB TO PARALLEL PRINTER ADAPTER

System Requirements:

- Windows® XP, Vista, 7, 8, 8.1
- One available USB port
- Intel-compatible 486DX-66 MHz CPU or higher

Note: These adapters are not capable of supporting any device other than a basic Parallel printer. These adapters do not support multi-function devices, e.g. Print/Copy/Scan/Fax or All-in-One printers. These adapters are not recognized by the computer as a Parallel or LPT port, they are recognized as USB Printing Support.

Package Contents:

16898

- USB to Centronics 36-pin Parallel printer adapter
- Driver CD (Manual only)
- Quick start guide

16899

- USB to DB25 Parallel printer adapter
- Driver CD (Manual only)
- Quick start guide

Note: These adapters utilize a driver that is built into the operating system. No separate driver is required.

Device Installation:

Step 1: Connect the printer to the USB to Parallel printer adapter and then connect the adapter to an available USB port on the computer. Windows will automatically find and install the USB to Parallel printer adapter and it will not require additional driver installation.

Step 2: Verify that the adapter was successfully installed by opening Device Manager and locating a device named "USB Printing Support" under "Universal Serial Bus Controllers".

Step 3: Use the Windows Add Printer Wizard to install the driver for the printer which will be connected to the adapter. Select "USB001 Virtual print port for USB" and do not print a test page when asked.

Note: If there is already another USB printer connected to the computer, then that device will be using USB001. In this situation USB002 must be selected for the printer connected to the adapter.

Step 4: Open the Printers folder or Devices and Printers in Windows 7, right-click the icon for the printer and then select "Properties" or "Printer Properties" in Windows 7 to open the Printer Properties window

Step 5: Click on the "Ports" tab and make sure that the two check boxes labeled "Enable bidirectional support" and "Enable printer pooling" are blank and not checked.

Step 6: Next, click on the "Advanced" tab and look for the four check boxes that will be near the bottom of that tab. Make sure that all four boxes are blank and not checked. After those boxes have been unchecked, select the radio button next to "Print directly to the printer" and then click "Apply".

Step 7: Finally, click on the "General" tab and then click on the "Print test page" button. The printer will print a Windows test page.

Accessing the User Manual:

Step 1: Insert the CD into the computer's CD drive

Step 2: Click on the 16898 and 16899 - USB to Parallel Adapter button.

Note: If AutoPlay is not enabled on the computer, then locate and double-click the Setup.exe file through Windows Explorer (Computer or My Computer) on the CD drive.

Step 3: Click on the User Manual button.

Technical Specifications:

| | 16898 | 16899 |
|-------------------|-------------------------------|-----------------------------------|
| USB Specification | 1.1 & 2.0 | |
| Connectors | USB A Male x 1 C36 Pin x 1 | USB A Male x 1 DB25 Female x 1 |
| Cable Length | 6 ft | |
| Cable Weight | 1.2 lbs | |
| Color | Beige | Blue |