

## **Manual for Cables To Go USB Card Reader – 29557**

### **Microsoft Windows 2000, Windows XP, & Windows Vista:**

To install the card reader do the following:

1. Insert the card reader USB cable into your USB port.
2. Windows will recognize the Card Reader and install 3 Removable Disks
  - a. The first removable disk will be for the slots on the rear of the unit.
  - b. The second removable disk will be for the slots on the front of the unit.
  - c. The third removable disk will be for the slots on the right side of the unit.

You can use multiple cards in the card reader when connected to a Windows as it is seen as three drives.

To unplug the card reader, you must click on the “Safely Remove Hardware” icon in the Windows system tray.

### **Apple OS X:**

To install the card reader do the following:

1. Insert the card reader USB cable into your USB port.
2. Plug a card into the card reader. It will show up as a removable disk.

You can only use a single card in the reader as OS X sees it as a single drive.

To remove the card, simply “eject” the drive.