

TRULINK® USB IR PC MEDIA REMOTE – 29662 / REMOTO DE MEDIOS TRULINK® USB IR PC – 29662 / TÉLÉCOMMANDE IR PC MÉDIA TRULINK® – 29662

System Requirements:

Pentium 4 or higher processor
Microsoft Windows® XP, Vista, or Windows® 7
Microsoft Internet Explorer 6.0 or later
One available USB port (USB 2.0, 1.1 compatible)

Installation Instructions:

Step 1: Connect the IR Receiver to an available USB port on your computer

Step 2: Follow the steps on the Found New Hardware Wizard which will allow Windows to automatically search for the appropriate driver. After following the prompts in the Found New Hardware Wizard the driver will be installed automatically.

Requerimientos del sistema:

Procesador Pentium 4 o mayor
Microsoft Windows® XP, Vista, o Windows® 7
Microsoft Internet Explorer 6.0 o posterior
Un puerto USB disponible (USB 2.0, compatible con 1.1)

Instrucciones de instalación:

Paso 1: Conecte el Receptor IR a un puerto USB disponible en su computadora

Paso 2: Siga los pasos en el Auxiliar de instalación de Hardware nuevo ("Found New Hardware Wizard") que le permite a Windows buscar el driver adecuado. Después de seguir los pasos en el Auxiliar de instalación de Hardware nuevo, el driver se instalará automáticamente.

Configuration nécessaire :

















Processeur Pentium 4 ou supérieur
Microsoft Windows® XP, Vista ou Windows® 7
Microsoft Internet Explorer 6.0 ou ultérieur
Un port USB disponible (USB 2.0, compatible 1.1)
















Instructions d'installation :

Étape 1 : brancher le récepteur IR sur un port USB disponible de l'ordinateur.

Étape 2 : suivre les étapes de l'assistant de recherche d'un nouveau matériel qui permet à Windows de chercher automatiquement le pilote de périphérique approprié. Une fois suivies les instructions de l'assistant de recherche, le pilote est installé automatiquement.

TRULINK® USB IR PC MEDIA REMOTE – 29662 / REMOTO DE MEDIOS TRULINK® USB IR PC – 29662 / TÉLÉCOMMANDE IR PC MÉDIA TRULINK® – 29662

Key Function		Description
	WWW	Starts the default Web browser and goes to the home page.
	Sleep	This button causes the computer to enter Sleep mode
	My TV	Open My TV application.
	My Music	Open My Music application.
	My Pictures	Open My Pictures application.
	My Videos	Open My Videos application.
	Record TV	Open Record TV application.
	Guide	Open TV Guide application.
	Live TV	Open Live TV application.
	DVD Menu	Open DVD Menu application.
	Play	Play DVD/VCD/Audio media
	Pause	Pause playing the media.
	Reverse	Fast reverse.
	Forward	Fast forward.
	Pre-track	Switches to the previous media track.
	Next track	Switches to the next media track.

Key Function		Description
	Stop	Stops playing the media.
	Record	Record the TV or copy the media to PC.
	Back	Goes back to a previous item.
	Information	Displays additional information when available.
	Direction Pad	Control up, down, left, right and OK key.
	Mouse Left	Mouse left key function.
	Mouse Right	Mouse right key function.
	Mouse Pad	Simulates mouse function.
	Volume Control	Control volume up and down.
	Channel Control	Control channel up and down.
	Mute	Mutes and Un-Mutes the computer volume
	Start Key	Open Media Center application.
	Close Key	Closes the active application.
	Clear Key	Clears the last command entered.
	Enter Key	Performs the keyboard “Enter” function.