

FIBER PULLING EYE

Package Contents:

- Simplex/Duplex Fiber Pulling Eye

Device Installation:

Step 1: Slide one end of the patchcord to be pulled into the cable netting. Make sure that the connectors are placed towards the top of the netting.

Step 2: Tape the open end of the cable netting down onto the strength member of the pulling eye using electrical tape. The tape should cover an area from 1" below the end of the cable netting.

Step 3: Braid the two strength members around the cable. Tape a 4" section of the strength member to the cable. Starting just below the cable netting, spiral wrap the tape around the cable.

*To reuse the pulling eye, carefully remove the tape applied and then repeat steps 1-3.